Setup guide for OLT and ONU in Bridge Configuration Port VLAN (JP)

AirLive XGSPON OLT-2XGS and ONU-10XG(S)-1004-10G

o [°] li **v** e[®]



How to setup the OLT and ONU in Bridge Mode in combination with a Router.

For the setup an AirLive GPON OLT-2XGS and an Airlive ONU-10XG(S)-1004-10G were used.

The setup is following the below diagram, please do **not** use VLAN: 0, 1, 2, 9, 8, 10, 4000, 4005, 4012-4017, 4095.



For this setup the ONU-10XGS-1004-10G should have Firmware V1.0.01-250121_SFU on it or higher. SFU meaning the ONU is set up to SFU mode by default.

The OLT-2XGS should have firmware V1.0.1R-24012025 or higher.

NOTE: When a warning message in the PortVLAN setup is shown "Warning: over ONU profile max port num." Then this means more than the 4 default LAN ports are being configured. Please go Point 2 in this guide to change this. This can also already be done before the setup in Point 1 is in made.

1: Login to the OLT management Web interface. The default IP is 192.168.8.200 using the AUX port. Make sure the PON mode is the correct one for the ONU used in this case XGS.

- 2: If we want to configure ONU access to Internet, we need to create a VLAN in OLT first.
- 3: Create a VLAN 100 (for this example) for Internet.
- 4: VLAN bindings for uplink GE port

please note: If the uplink port is in the untag mode, PVID (default VLAN id) needs to be configured (100 in this example).

5: Open ONU list page, Select the PON port where ONU is located. Find out what ONU you want to configure. Check the ONU status and ensure the ONU is in Online state.

6: Click on the ONU configuration page to configure "tcont", "gemport", "Service", "Service Port" and other parameters.

7: On the "PortVLAN" page, for the ONU, the Mode needs to be configured as "Tag", PortType needs to be configured for "Eth" and Port Id needs to be configured for each of the ethernet ports of the ONU. (default profile is 4 LAN ports, when you have more LAN port on the ONU to configure, go to Point 2 first the bottom of this guide).

8: You can configure ONU DHCP Server on "DHCP server" page, this should be disabled.

9: Press "SAVE" in the top bar of the OLT so save the complete configuration.



1: In the OLT Configuration select "VLAN" and make a VLAN ID in this example we make VLAN 100.

airli▼e®	VLAN VLAN Port QinQ/Translation
OLT Information	New VLAN
OLT Configuration VLAN Uplink Port PON	Mode single VLAN ID 100 Description VLAN100 Add Delete
LACP QoS	VLAN Table
ACL	VLAN ID Description Edit Delete
IPv6 ACL	1 default 🖉
IGMP	
IPv6 MLD	
STP	
Loopback	
DHCP	

2: Bind the Uplink GE port go the "VLAN" >> "VLAN Port", in this example all ports were bind to the VLAN 100. Make sure the Uplink is in "Untag" mode.

airlive®	VLAN VL	AN Port	QinQ)/Translatio	'n				
OLT Information	Port VLA	Port VLAN Configuration							
OLT Configuration	VLAN ID	ſ	100		~	1			
VLAN	Port ID	Mode	e	Forbidden	Tag	Untag			
Uplink Port	GE0/1	Hybrid	~	0	0	۲			
PON	GE0/2	Hybrid	~	0	0				
MAC	GE0/3	Hybrid	~	0	0				
LACP	GE0/4	Hybrid	~	0	0				
QoS		Submit	Res	et					
ACL	Port VI A	Table	rttes	<u>c</u>					
IPv6 ACL		Tuble							
IGMP	VLAN ID	Tag Ports	Unta	ng Ports					
IPv6 MLD	1		GE1	GE2 GE3	GE4				
STP	100		GE1	GE2 GE3	GE4				
Loopback									

3: When the Uplink port is in "Untag" mode, the PVID (default VLAN id) needs to be configured. Go to "Uplink Port" >> "Configuration". Change the PVID for the uplink to 100 (in this example).

airlive®															
	Informati	on Optical I	Information	Perf-Stats Information		tion	Configuration		on Perf-Stat	n Perf-Stats Configuration Protection			Switch Group		
OLT Information	Information GE Configuration														
OLT Configuration									Sto	rm(0 64-1000	000fps)	Ofps) Rate(0 64-			
VLAN	Port ID	Description	Admin Status	Speed		Isolate		D	Broadcast	Multicast	Unknown Unica	ast	Ingress	Egress	
Uplink Port	GE0/1			Auto	~		1	~	512	0	512	0		0	
PON	GE0/2			Auto	~		1	~	512	0	512	0		0	
MAC	GE0/3			Auto	~		100	~	512	0	512			0	
LACP	020/0		-		-	-	100	_		Ļ	512			<u> </u>	
QoS	GE0/4			Auto	~	~	1	~	512	0	512			0	
ACL	Submit	Reset													
IPv6 ACL															
IGMP															
IPv6 MLD															



Make sure the ONU has been connected to the OLT via its PON port and a Splitter. Click ONU "AuthList" it could be that your ONU has already been automatically added, if this is the case you can go to step 5 directly. If not follow the steps below.

Click on "ONU Configuration" and select "ONU Autofind" when your ONU has been connected correctly. It will show up here. Select the ONU you want to add (when there are several) and click on "Add".

oirli v e®	
	Automatic Discovery Aging Time
OLT Information	Automatic Discovery
OLT Configuration	
ONU Configuration	Port ID PON1 V
ONU AuthList	Search Info Search
ONU AutoFind	
ONU AutoLearn	Refresh Confirm All
ONU Upgrade	Index Sn SnPw loid loidpy Action
Rogue ONU	1 GPON000004c 1234567890 user NULL Add
Profile Configuration	
System Configuration	

Click on "Submit" on the next page which will automatically appear.

airli▼e®		
	Automatic Discovery	Aging Time
OLT Information		
OLT Configuration	Add Onu	
ONU Configuration	PON Num	
ONU AuthList		
ONU AutoFind	ONU Num	3
ONU AutoLearn	Auth Mode	Sn 🗸
ONU Upgrade	Onu Sn	GPON000004c
Rogue ONU		
Profile Configuration	ONU Profile	default 🗸
System Configuration	Submit Back	

The ONU will now be shown and when connected correctly will show "Enable"

airli▼e®								Save 🔴	Log			
	Automatic Dis	covery Agin	g Time									
OLT Information	ONU Status	Information										
OLT Configuration												
ONU Configuration	Port ID	Port ID PON1 V										
ONU AuthList	total-3, logging-0, offline-0, syncMib-1, configFail-0, working-2											
ONU AutoFind	Refresh											
ONU AutoLearn	ONU ID	Admin State	OMCC State	Phase State	Description	Last Register Time	Last Deregister Time	Last Deregister Reasor	Alive Time			
ONU Upgrade	GPON0/1.1	enable	enable	working	N/A	1970:01:01 08:01:17	N/A	N/A	02:33:36			
Rogue ONU	010110/111								02.00.00			
Profile Configuration	GPON0/1:2	enable	enable	working	N/A	1970:01:01 08:01:16	N/A	N/A	02:33:37			
System Configuration	GPON0/1:3	enable	enable	syncMib	N/A	N/A	N/A	N/A	N/A			



5: Configure the ONU, Click on the "ONU List" in the top right corner of the OLT menu bar.

The active ONU's will now be shown, select the ONU you want to configure (make sure the status is "Online") and click on the "Config" button.

oirlive							Sa	ive	•	Log	Status	ONU list	Logout
	ONU List ONU Status	ONU Optical Inf	ormation	ONU Ve	ersion Info	ormation C	NU Manua	I Add O	NU Allowlist	ONU Sta	atistics		
OLT Information	ONU Authentication	Information											
OLT Configuration	Port ID PON1	~											
ONU Configuration													
Profile Configuration	Search Mode All	~		-									
System Configuration	ONU Count 1/1		Sear	cn									
	Delete All Delete Offline Refresh												
	ONU ID Status	Description Model	Profile	PON Type	Mode In	fo	Action						
	GPON0/1:1 Online	GPON0/1:1 H365	default	XG-PON	SN G	PON00dc720	<u>Config</u>	eactivate	Delete Modif	y <u>Optica</u>	l Info De	tail Info Reb	poot

6: Setup the "tcont", "gemport", "Service", "Service Port" and other parameters.

Setup the "tcon" default value is 1, in this example for name, the name test was used.

airlive®	ONU List ONU Status ONU Optical Information ONU Version Informatio
OLT Information	Tcont Gemport Service Service Port PortVLAN Multicast Port
OLT Configuration	Security Loopback Detection H 248 MAC ACL
ONU Configuration	ONU Treat Information (CLOTIC DONISION ACTION
Profile Configuration	OND TCONT INFORMATION (SECT:0 PON:1 OND:1)
System Configuration	Tcont ID Name DBA Profile Action
	1 test default1 <u>Delete</u>
	Add ONU Tcont
	Tcont ID 2
	Tcont Name
	DBA Profile Name default1
	Commit

Setup the "gemport" the default value is 1, make sure the TcontID select is 1 (the one previously made. The name used in this example is test.

airlive	ONU List ONU Status ONU Optical Information ONU Version Information ONU Manual Add ONU Allowlist
OLT Information	Tcont Gemport Service Service Port PortVLAN Multicast Port IP Host IGMP MAC WAN I
OLT Configuration	Security Loophack Detection H 248 MAC ACL
ONU Configuration	
Profile Configuration	
System Configuration	Gemport ID Name Tcont Downstream Action
	1 test 1 default <u>Delete</u>
	Add ONU Gemport
	Gemport ID 2
	TcontID 1
	Gemport Name
	Downstream Traffic default
	Commit



Setup the "Service", make sure to select Gemport ID 1 (the one just made) and for VLAN mode select "Tag" for "VLAN List" enter the value 100, this is the VLAN id made in the OLT previously.

oirlive®	ONU List ONU	U Status ONU Optical Information ONU Version Information ONU Manual Add ONU Allowlist
OLT Information	Tcont Gempo	ort Service Service Port PortVLAN Multicast Port IP Host IGMP MAC WAN DI
OLT Configuration	Security Loon	phack Detection H 248 MAC ACL
ONU Configuration	ONU Comico I	
Profile Configuration	UNU Service I	Information (SLUT:0 PON:1 ONU:1)
System Configuration	ServiceName	Gemport VLAN Mode VLAN List CoS List Port Action
	ser_1	1 Tag 100 N/A N/A Delete
	Add ONU Serv	vice
	ServiceName	ser_2
	Gemport ID	1 •
	VLAN Mode	Tag V
	VLAN List	100 (X,X or X-X;0 for all;max 12 VLANs)
	CoS List	N/A (X,X or X-X;)
	PortType	N/A V
	Commit	

Setup the "Service Port" enter the User VLAN and Translate VLAN in this example both are 100. (as this example is using VLAN 100).

airlive												5	ave	•
	ONU List ON	U Status (ONU Optica	Informa	tion ONU	Version In	format	ion O	NU Mai	nual Add	ONU	Allowlist	ONU Stat	istics
OLT Information	Tcont Gempo	ort Service	Service	Port	PortVLAN	Multicast	Port	IP Ho	st I	GMP I	мас и	VAN DH	CP Server	WiFi
OLT Configuration	Security Loo	nhack Detect	ion H 24	18 MAC	ACL									
ONU Configuration	ONUL Complete	Doub Info (6												
Profile Configuration	UNU Service	Port Inio (:	SLUT:U PU	N:I UNU	:1)									
System Configuration	Service Port	Gemport ID	Begin Vid	End Vid	Outer Vid	Inner Vid	VLAN	SVLAN	Mode	Enable	Descrip	tion Action	,	
	1	1	100	100	N/A	N/A	100	N/A	1:1	YES	N/A	Delet	2	
	Add ONU Ser Service Mode Service Port 1 Gemport ID User VLAN Translate VLA Description Commit	CVLAN CVLAN D 2 1 AN N/A												



7: As the ONU is in SFU mode the Ethernet port(s) needs to be setup directly.

On the "PortVLAN" page, for the ONU, the Mode needs to be configured as "Tag", PortType needs to be configured for "Eth" and Port Id needs to be configured for each of the ethernet ports of the ONU. But less can also be set up. When the ONU has 4 LAN ports all need to be set up here. First Enter "1" for LAN port 1, then enter the VLAN ID which in this example is 100 and press commit. Now the same thing needs to be setup for LAN port 2. Follow the same steps but now enter "2" at Port Id and press commit again. And again, do the same for ports 3 and 4 and so on. Now the added ports are connected to Internet.

Note: When the warning message "Warning: over ONU profile ma port num." appears. Then please go to point 2 to make a new profile with your correct number of LAN ports.

In the below example only LAN port 1 is shown.

airli∎e®						Save	Log	Status ONU list	Logout
	ONU List ONU Status	ONU Optical Infor	mation ONU Version	n Information ONU M	Ianual Add ONU	Allowlist ONU Statisti	s		
OLT Information	Tcont Gemport Se	rvice Service Port	PortVLAN Multica	ast Port IP Host	IGMP MAC E	DHCP Server Misc T	R069 Security	Loopback Detection	H.248
OLT Configuration	MAC ACL								
ONU Configuration	ONU PortVLAN Info	SLOT:0 PON:1 ONU	1:1)						
Profile Configuration						1	1		
System Configuration	PortName Mode VLA	N VLAN Priority(tag)	Default VLAN(hybrid)	Default Priority(hybrid)	CVLAN(translate)	CVLAN Priority(translate)	SVLAN(translate)	SVLAN Priority(translate)	Action
	eth_0/1 Tag 100	0	N/A	N/A	N/A	N/A	N/A	N/A	<u>Delete</u>
	Add ONU PortVLAN								
	Mode Tag	~							
	PortType Eth	~							
	Port Id 1								
	VLAN ID 100								
	VLAN Priority N/A		(0-7)						
	Commit								



8: To receive the IP address from the Router on the computer, which is connected to the ONU, please make sure the DHCP server on the ONU is turned off. If this is not the case, the computer will get an IP address from the ONU and Internet will not work correctly.

In the setup menu select "DHCP Server", at DHCP Server select "Disable" from the pull-down menu and press Submit. After 1 to 2 mins the computer connected to the ONU will receive an IP address from the Router. If this is not the case, then unplug the RJ-45 cable from the computer and plug it back in.

When the DHCP Server is already disabled no settings need to be changed.

airlive®								Save	•	Log	Status	ONU list	Logout
••••••	ONU List ONU Status	ONU Optical Inform	ation	ONU Version Informa	ation ONU	Manual Add	d ONU Allow	list ONU St	atistics				
OLT Information	Tcont Gemport Serv	rice Service Port	PortVLA	AN Multicast Por	t IP Host	IGMP	MAC DHCP :	Server Miso	TR069	Security	Loopback	Detection	H.248
OLT Configuration	MACACI												
ONU Configuration	MAC ACL												
Profile Configuration	DHCP Server Configur	ation (SLOT:0 PON:	1 ONU:	:1)									
System Configuration	LAN IP Address	192.168.1.1											
-,	LAN Subnet Mask	255.255.255.0											
	DHCP Server	Disable	~										
		Submit											
	LAN IPv6 Address												
	Prefix Mode	Static											
	Static IPv6 Address												
	LAN Prefixlen	64	(•	48-64)									
	DHCP Server IPv6	Enable	~										
	Preference Time	10000	(0-4294967295)									
	Valid Time	20000	(0-4294967295)									
	Beginning IPv6 Address	0001:0001:0001:000	01 (нннн:нннн:нннн:н	HHH)(Last 6	4 bits of IP	address)						
	Ending IPv6 Address	0002:0002:0002:00	02 (1	нннн:нннн:нннн:н	HHH)(Last 6	4 bits of IP	address)						
	DNSv6 Master	PC	•										
	DNSv6 Slave		_										
	IPv6 Gateway	::											
	RA	Active											
	Manage	disable	~										
	Other	enable	~										
	Max Interval	600	(1-1800)s									

To see the settings of the ONU (which the OLT sent to the ONU), please connect to the ONU with a PC, and enter the default IP address of the ONU in a browser. The default IP address is 192.168.1.1. You would need to enter a Fixed IP address in the network of the computer when the DHCP server of the ONU is turned off.

9: Remember to Press "SAVE" in the top bar of the OLT so save the complete configuration.



Point 2 (only when warning message appears)

Setting up the XGSPON OLT-2XGS ONU-10XG(S)-1004-10G using Bridge mode and PortVLAN gives an error, showing Max port number reached with Default ONU profile in the OLT is used.



Answer:

When you get this error message it means that the number of LAN ports on your ONU is higher than the number of LAN Ethernet ports specified in the ONU Profile used in the OLT.

To change this, you would need to make an ONU profile with the correct number of Ethernet Port for your ONU. When this new profile is used you will be able to add all the ONU LAN ports to the PortVLAN setup.

1: In the OLT Webui go to Profile Configuration >>> ONU Profile. If you would like to see the number of Ethernet ports used on the Default or any other profile, click on "Detail" behind the Profile name.

To add a new Profile, click on "Add Profile" a new page will open.

airlive®						
••••••	Information	Add Profile				
OLT Information	ONU Prof	ile				
OLT Configuration	Refresh					
ONU Configuration	Profile ID	Profile Name	Max Tcont	Max Gemport	Max Veip	Action
Profile Configuration	0	default	255	255	1	Details
ONU Profile			1	1	I	
DBA Profile						
Traffic Profile						
Line Profile						
Service Profile						
Alarm Profile						
Pri Profile						
IGMP Profile						
Format Profile						
Bind Profile						
System Configuration						



2: Add Profile

Enter your Profile ID number as will Profile Name and Description. Enter all the necessary information for your ONU. In this example Max Eth was setup to 5 as the ONU-10XG(S)-1004-10G used has 5 LAN Ethernet ports.

After entering all the information press "Commit" to save your profile.

irlive			Save	•	Log	Status	ON
	Information Add Profile						
OLT Information	ONU Profile Modify						
OLT Configuration	Commit						
ONU Configuration	Brofile ID						
Profile Configuration	FIGHIE 1D						
ONU Profile	Profile Name	ONU_5Eth					
DBA Profile	Description	ONU_5Eth					
Traffic Profile	Max Tcont	8					
Line Profile	Mary Company						
Service Profile	Max Gemport	32					
Alarm Profile	Max Eth	5					
Pri Profile	Max POTS	0					
IGMP Profile	Max IDHoct	2					
Format Profile	Hax IFHOSE	<u> </u>					
Bind Profile	Max IPv6Host	0					
System Configuration	Max Veip	1					
	Service ability	Disable 🗸					
	Service ability N:1	yes 🗸					
	Service ability 1:M	yes 🗸					
	Service ability 1:P	yes 🗸					
	WiFi mgmt via non OMCI	Disable 🗸					
	OMCI send mode	async 🗸					
	Default Multicast range	none 🗸					

3: Add new Profile to ONU AutoLearn.

Note if you have already added your ONU to the OLT with the default profile, you would need to delete the ONU and re-add it again after you have added the new Profile to ONU AutoLearn.

Go to ONU Configuration >>> ONU AutoLearn >>> Default ONU Profile.

From the Pull-down menu at Default ONU Profile select your correct Profile. After it has been selected press "Apply" to save the settings.

airlive		Save	•	Log Status	ONU list								
•••••	ONU AutoLearn ONU AutoBind ONU AutoDelete ONU Scheduled Reboot												
OLT Information	Automatic Learn												
OLT Configuration													
ONU Configuration	Default ONU Profile default												
ONU AuthList	Plug and Play												
ONU AutoFind	Default VLAN												
ONU AutoLearn													
ONU Upgrade	Variable VLAN disable I (1-3582)												
Rogue ONU													
ONU Common Service	PON ID Enable Line Profile Srv Profile Alarm Profile	Pri Pro	ofile	Format Profile									
Profile Configuration	PON1 Enable	▼ N/A	~	N/A	~								
System Configuration	PON2 Enable V N/A V N/A V N/A	✓ N/A	~	N/A	~								
	Apply Refresh			1									



4: After adding the ONU to the OLT, the Profile shown should be your new selected profile.

You can now setup the ONU-10XG(S)-1004-10G without the PortVLAN error message coming back.

airlive®	Save 🔵 Log Status ONU list Logout
	ONU List ONU Status ONU Optical Information ONU Version Information ONU Manual Add ONU Allowlist ONU Statistics
OLT Information	ONU Authentication Information
OLT Configuration	Port ID PON1 V
ONU Configuration	
ONU AuthList	Search Mode All
ONU AutoFind	Search Into Search
ONU AutoLearn	ONO COURT 1/1
ONU Upgrade	Delete All Delete Offline Refresh
Rogue ONU	ONU ID Status Description Model Profile PON Type Mode Info Action
ONU Common Service	GPON0/1:1 Online GPON0/1:1 V305 ONU_SEth XGS-PON SN GPON00000887 Config Deactivate Delete Modify Optical Info Detail Info Reboot
Profile Configuration	
System Configuration	

PortVLAN is now able to add all 5 LAN ports of the ONU-10XG(S)-1004-10G.

oirlive®	ONUL List of		tatus	ONUL Optical Infor	mation ONUL Versio	a Information ONU h	April Add ONU	Save	Log	Status ONU list	Logout		
OLT Information OLT Configuration	Tcont Gem	port	Servi	ce Service Port	PortVLAN Multic	ast Port IP Host	IGMP MAC I	DHCP Server Misc T	R069 Security	Loopback Detection	H.248		
ONU AuthList	ONU PortVLAN Info (SLOT:0 PON:1 ONU:1)												
ONU AutoFind	PortName	Mode	VLAN	VLAN Priority(tag)	Default VLAN(hybrid)	Default Priority(hybrid)	CVLAN(translate)	CVLAN Priority(translate)	SVLAN(translate)	SVLAN Priority(translate)	Action		
ONU AutoLearn ONU Upgrade	eth_0/1	Tag	100	0	N/A	N/A	N/A	N/A	N/A	N/A	Delete		
Rogue ONU	eth_0/2	Tag	100	0	N/A	N/A	N/A	N/A	N/A	N/A	Delete		
ONU Common Service	eth_0/3	Tag	100	0	N/A	N/A	N/A	N/A	N/A	N/A	Delete		
Profile Configuration	eth_0/4	Tag	100	0	N/A	N/A	N/A	N/A	N/A	N/A	Delete		
System Configuration	eth_0/5	Tag	100 0 N/A		N/A	N/A	N/A	N/A	N/A	N/A	Delete		
	Add ONU PortVLAN												
	Mode		ag	`									
	PortType	E	th	~									
	Port Id												
	VLAN ID												
	VLAN Priori	ty N	/A		(0-7)								
	Commit												

Remember to Press "SAVE" in the top bar of the OLT so save the complete configuration.