airlive®

www.airlive.com

# Declaration of Conformity

We, Manufacturer/Importer

**AirLive Technology Corporation**
**4F, No.132, Lane 235, Baoqian Rd., Xindian Dist.,**
**New Taipei City 23145, Taiwan**

Declare that the product

**8-Port Full 10G RJ-45 Multi Gigabit Switch**
**Live-10TX800**
**8-Port Full 10G WebSmart RJ-45 Multi Gigabit Switch**
**WEB-10TX800**

**is in conformity with**

In accordance with 2014/30/EU and 2014/35/EU Directive

| Clause | Description |
|--------|-------------|
| ■ **EN 55032:2015/A1:2020** | Electromagnetic compatibility (EMC) |
| ■ **EN IEC 62368-1:2020+A11:2020** | Electromagnetic compatibility (LVD) |
| ■ **CE marking** | C E |

**Manufacturer/Importer**

Name : A van Rossem  Position/ Title : Product Manager
Place : Republic of China (Taiwan)   Date : June 2024



Live-10TX800



WEB-10TX800

# Regulatory Approvals

● **CE Statement**

This product complies with the 2014/30/EU and 2014/35/EU directives, including the following safety and EMC standards:

■ **EN 55032:2015/A1:2020**
  Electromagnetic compatibility (EMC)

■ **EN IEC 61000-3-2:2019/A1:2021**
  Electromagnetic compatibility (EMC)

■ **EN 61000-3-3:2013/A2:2021**
  Electromagnetic compatibility (EMC)

■ **EN 55035:2017/A11:2020**
  Electromagnetic compatibility (EMC)

■ **EN IEC 62368-1:2020+A11:2020**
  Electromagnetic compatibility (LVD) - Safety

● **CE Marking Warning**

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

● **RoHS Statement**

This product complies with RoHS directive 2011/65/EU and amendment Commission Delegated Directive (EU)2015/863.

■ **IEC 62321-3-1:2013**

■ **IEC 62321-5:2013**

■ **IEC 62321-4:2013+AMD1:2017**

■ **IEC 62321-7-1:2015**

■ **IEC 62321-7-2:2017**

■ **IEC 62321-6:2015**

■ **IEC 62321-8:2017**

CE AirLive Technology Corporation declares that this device is in compliance with the essential requirements and other relevant provisions of directive 2014/30/EU.

**www.airlive.com**

*Quick Setup Guide* ▶

▼ *Installation Steps*

**Figure A**



## LED DEFINITIONS

| Power | Red ON | Power is ON and Normal. |
|---|---|---|
| | Red OFF | The switch is not receiving power. |
| **Port LED (Green)** | Green ON | 2.5G/5G/10G Link Connection is normal. |
| | Green Flashing | Data transmission is normal. |
| | Green OFF | Link is Offline. |
| **Port LED (Yellow)** | Yellow ON | 100/1000M Link Connection is normal. |
| | Yellow Flashing | Data transmission is normal. |
| | Yellow OFF | Link is Offline. |

**EN** English

**Installation Step:**

1. Remove the switch and accessories from the package.
2. Connect power to the switch. Make sure that "Power" LED is on.
3. Check the Port LED indicator status. When a device is connected the port light up.
4. For more product information visit www.airlive.com.

**EN** English

**Important Information for model WEB-10TX800 only.**

- The default IP address: *192.168.2.1*
- The default username / password is *admin*

**Installation Step:**

1. Set your PC's IP address to 192.168.2.50.
2. Open your web browser and enter "192.168.2.1" to get into the switch Web Management.
3. Enter "admin" for username, "admin" for password.