

Front Panel Lights Information of the AirLive GPON OLT-121.



Figure 1 Front Panel Lights

LED	Mark	Status	Description
Power	PWR	On	Device is Powered up.
		Off	Device is Powered down.
System	SYS	On/Off	System is booting or halt.
		Blink	System is running normally.
Registration	PON	On	At least one ONU has registered to this PON port.
		Off	No ONU registered to this PON port.
Interface	10GE	On	Port is link up.
		Off	Port is link is link down.
	GE1 GE2	On	Green on: Port is link up.
		Off	Green off: Port is link down.
		Blink	Yellow blink: Port is sending or/and receiving data.

Table 1 Panel Lights